Cetol® Maintenance APPLICATION

Working With Cetol® Maintenance

Preparation Procedures

Previous Sikkens-Coated Surfaces

- 1. Spray the surface with clean water, wetting the wood.
- 2. Clean the surface with a solution of 2 ounces of 100% powdered Tri-Sodium Phosphate (TSP) or phosphate-free substitute plus 1 quart of liquid bleach in 3 quarts of water. Apply this solution generously to the wood with a garden pump sprayer.
- 3. Let the solution sit on the wood for 15-20 minutes. During this period, scrub the surface with a hard bristle brush. Do not let the solution dry on the wood. Keep it wet.
- 4. Power wash the cleaning solution from the wood with clean water. To prevent damaging the wood, do not exceed 500 psi. The nozzle must be a maximum of 1 foot from the surface for full effectiveness.
- 5. Let the surface dry for 3 days before application.

Tips

- It is always recommended to perform a one coat test sample to check for desired results.
- Fill all joints, cracks, nail holes, if needed, with a good quality polyurethane or acrylic caulk/filler.

Cetol® Maintenance APPLICATION

Application Procedures

Coverage area for Cetol Maintenance is 300-400 sq. ft. /U.S. gal. (smooth wood) and 150-225 sq. ft./ U.S. gal. (rough wood).

- 1. Follow the preparation procedures
- 2. Apply one coat of Cetol Maintenance
- 3. Clean tools with mineral spirits

Application Do's...

- Apply over existing Cetol 23 Plus or Cetol Log & Siding
- Apply only when the surface is in good condition and has been maintained according to Sikkens maintenance guidelines
- Apply when the surface and air temp is 50°F/10°C to 95°F/35°C
- Saturate all end grains, nail holes, cavities, and cracks in the wood
- Apply a liberal coat in the direction of the wood grain using a long haired natural bristle brush (Cetol Maintenance may be sprayed when backbrushed)
- Maintain a wet edge to prevent lap marks and missed areas
- Stir before using
- · Intermix batches to ensure consistency

Application Don'ts...

- Do not apply on decks, doors, outdoor furniture or fences
- Do not apply over Cetol Door & Window, Cetol SRD or Cetol DEK Finish
- Do not apply on raw wood
- Do not use for marine applications
- Do not apply when the surface is hot to the touch
- Do not apply when rain, dew or frost is present, or expected within 5 hours of application
- Do not thin

Schedule for Cetol Maintenance Maintenance Procedures

Proper maintenance starts with visual inspection. Apply Cetol Maintenance every 2 to 3 years. However, as weathering, exposure, and altitude can vary widely, maintenance may be needed sooner and should be performed when visually required regardless of time frame.

- 1. Follow the preparation procedures listed above
- 2. Apply one coat of Cetol Maintenance